

Sefelec sas 19 rue des Campanules F-77185 Lognes France Tel: +33 (0)1 64 11 83 40

## MAIN FIRMWARE AND FUNCTION CARD

## **UPDATE PROCEDURE**

## **SEFELEC DEVICES**

### (56-H, 56-D, 56-S, 506-H, 506-D, 506-S, 32-C, 1000-M, 1500-M)







# CONTENTS

1.	Introduction	. 2
2.	Operating System & BSP update	. 2
3.	Function cards firmware update	. 4
4.	Main firmware update	. 6



### 1. INTRODUCTION

This procedure details the operations to be carried out to update the 3 on-board software packs of the devices:

- Pack1: Operating System & BSP (mentioned BSP in the device)
- Pack2: Firmware of the function cards.
- Pack3: Main firmware of the Human Machine Interface (HMI)

https://sefelec.fr/Téléchargement-c220.html

In the event of a problem, contact the after-sales service at the following e-mail address:

ServiceSefelec@Eaton.com



The updates do not systematically concern the 3 packs. They can be limited to one or two software packages.

#### 2. OPERATING SYSTEM & BSP UPDATE



Before installing a new version of BSP it is recommended to make a backup of the parameter and result files on a USB stick and to restore them after the update.

See paragraph 6.9 of the device manual for backing up files.

• For main Firmware versions from 1.3.8 included, use the "All parameters" line.

• For main Firmware versions before 1.3.8, repeat the operation of saving the parameters for each function of the device



The update files must be added to the root of the USB key used for the update:

appli.gup36.3b.ubi
gmc136\_version
imx6dl-gmc136-gup36.3.dtb
netEnv.txt
rootfs.cpio
rootfs.gup36.3b.ubi
rootfs.tar
u-boot.gmc136.imx
u-boot-nand.gmc136.imx
uEnv.txt
updater.gmc136
zImage

Once the files have been copied to the root of your USB drive, plug the drive into one of the USB ports on the front of the device.

Switch off the device and restart it (ON / OFF button).

The update will be launched automatically upon reboot if the key is detected. The update starts shortly after the white "EATON" screen appears. Information on the progress of the update is displayed.

At the end of the update, you are prompted to remove the USB stick, the device will boot with the new version of Operating System and BSP.



It is possible that the USB key is not detected fast enough during the boot, causing the device to reboot normally without any update. If that append try the procedure again. If it still doesn't work, you can try another USB key before contacting our services.



NOTE

Once the update is complete, it is recommended to delete the update files from the USB stick from a computer so that the device does not accidentally launch a new update of its Operating System & BSP during a normal restart

NOTE



### 3. FUNCTION CARDS FIRMWARE UPDATE

The function card firmware file downloaded from our site in the format '**eaton-maj-fct.zip**' must be copied to the root of a USB stick.



Do not rename or unzip the downloaded file

From the "General settings" menu, press the About area of the "System" line:

<b>Ceneral settings</b>					
Sound :	Settings				
Time - Date :	11:13 - 2019/04/10				
Access :	Administrator				
Interface :	RS232				
System :	About				
Restore :	Default				

Then from the following screen:





Press the area indicating function card Firmware Update to obtain the following screen:

<b>&lt;</b> System settings <b>†</b> 14:07						
Main Firm	<b>Firmware update</b> Insert a USB stick with the new software version. Do not turn off the power during the update operation.					
Firmwares	Update					
BSP versi	on : Unknown					

Press the "Cancel" button if you do not want to run the update.

Insert the USB key with the update file ("eaton-maj-fct.zip").

Then press the "Update" button and follow the instructions



It is important that the device is not turned off during the update

NOTE



After the update you should restart the device manually to ensure proper operation



### 4. MAIN FIRMWARE UPDATE

SEFELEC	<b>11:13</b> 2019/04/10		
ΜΩ	pA	Sequence	
			\$
RS232 Baud:19200			

From the start-up menu, press the configuration button (gear):

From the "General settings" menu, press the About area of the "System" line:





To obtain the following screen:

Model :	SEFELEC1500M				
Serial number :	1842499				
Main Firmware :	V0.1.12				
	Update				
	V8_1.11				
Firmwares :	V9_2.2				

The main HMI firmware file downloaded from our site in 'eaton-maj.zip' format must be copied to the root of a USB stick.



Do not rename or unzip the downloaded file

Then from the following screen:





Press the button "Update" to obtain the following screen:



Press the "Cancel" button if you do not want to run the update.

Insert the USB key with the update file ("eaton-maj.zip").

Then press the "Update" button and follow the instructions



It is important that the device is not turned off during the update

NOTE



After the device rebooted once you should restart the device manually to ensure proper operation